

Aquafix Laboratories

Anaerobic Micronutrients Analysis



1. Label each sample bottle and fill bottles completely full, ensuring that the sample is representative (mixed well). The bottles must be sealed and leak-proof.

FOR BEST RESULTS: Please submit one full container (1L) of each, digestate and influent samples. If digestate is inaccessible, effluent is an acceptable alternative.

2. Seal sample bottles in Ziploc bag provided. Place samples in original box with provided frozen ice pack.
3. Attach included shipping label over the original label and tape the box closed.
4. **Call us at 888-757-9577 to schedule your free pick up.**
 - a. Call prior to 9 am CST to arrange same day pickup Monday - Wednesday



SCAN ME

Use the QR code above
or visit **teamaquafix.com/submit-anaerobic-sample** to fill out your
online chain of custody.



PO Box 8682
Madison, WI
53708-8682

P: 888.757.8577
F: 866.636.1864

support@teamaquafix.com
www.teamaquafix.com